



Specialty Flooring Solutions

INSTALLATION INSTRUCTIONS

COR Series – Rolled Polyvinyl Flooring

UPON DELIVERY OF PRODUCT

1. **VERIFY** packing slip matches with product and order
2. **INSPECT** delivered product thoroughly. Report any discrepancies of original order, product defects, etc. No reimbursement/warranty claim will be given for labour on material installed with visual defects. Any defects – size, color or otherwise – must be reported to the place of purchase prior to installation.
3. **STORE** product and adhesives in a clean, dry environment with temperatures between 70 and 95 F.
4. **READ** product and sub-floor preparation instructions, warranty and other disclaimers carefully and completely before beginning any installations.

INTRODUCTORY NOTE: This installation guide is intended to provide the necessary information for the proper installation of Perfect Surfaces COR Series rolled flooring. These instructions are believed to be based on accepted industry standards and are provided for informational use only.

PERFECT SURFACES DOES NOT WARRANTY ANY INSTALLATION PERFORMED PURSUANT TO THESE INSTRUCTIONS OR OTHERWISE AND SPECIFICALLY DISCLAIMS LIABILITY FOR ANY DIRECT OR INDIRECT PERSONAL INJURY, PROPERTY DAMAGE OR OTHER COSTS OR LOSSES RESULTING FROM INSTALLATION.

Begin by sweeping garage floor clean of debris before unrolling the Garage Floor Protector. Wipe up any oil and chemicals from floor. In most cases, the product is rolled on a PVC or paper core. The product will initially have curl marks—this is normal.

INSTALLATION

Garage Floor

1. For best results, start unrolling process at the garage entrance; finishing at the back of the garage. Using a wide push broom, push any air out from center and work your way outward side-to-side and length-to-length. It will take some time for most curl marks to lay flat. In cool to cold conditions, it may take 72+ hours before all curls have relaxed. Depending on the temperature, product may expand or contract somewhat during process. It is OK to park your car on the Floor Protector during this time.
2. For custom fit, allow product to relax for a minimum of 72 hours in place before trimming around edges and corners. After product has been allowed to relax in place, overlap seams by 2-3 inches and tape underneath edges and in between seams using GatorTAPE. An alternate method to overlapping is to allow the seams to meet, followed by joining the seams using GorillaCOR Seam Tape.
3. If, after 72 hours, curls are present, turn up the heat or place in direct sunlight.

Interior, Exterior or Commercial Use

If product is used under extreme heat, such as direct sunlight, the product may expand or contract a small amount after laying flat. For custom fit, allow product to relax in place before trimming around edges and corners.

This product will relax over time and will look better the longer it sets.

Cleaning & Maintenance

Clean surface easily with soap and water, using a broom or sponge squeegee. Mild soap and detergents are usually effective. Never leave harsh detergents or chemical on surface. You may choose to use household vinyl cleaners to increase longevity and to remove stubborn debris. This is not a stain-proof product. Certain chemicals, rubber tires, inks and dyes may cause permanent staining. For non-permanent stains, brake and tool cleaner can be used, but may cause discoloration. Never use harsh chemicals like tar remover or kerosene on this surface.

Caution & Safety Warning

This surface may become slippery when moisture, extreme cold or debris are present. Proper care and cleaning will reduce the likelihood of slips and falls. Always clean up any spills immediately to prevent hazardous, slippery conditions. Dispose of hazardous materials properly and never wash chemicals into the sewer system. Failure to remove harsh chemicals immediately may cause damage to the surface.



2007 - 4 Highland Park Green NE
Airdrie, AB T4A 0X3



587.775.8838
888.363.6289



www.perfectsurfaces.ca
sales@perfectsurfaces.ca